



TYRE REPAIR

SN90117-KS-34895

TYRE REPAIR seals punctures and inflates tyres without removing the wheel. Seals punctures up to 5 mm. Inflates the tyre up to a pressure at which one can continue to drive.

BENEFITS

- Instantly repairs and inflates punctured tyres
- Seals punctures up to 5 mm in the running surface of the tyre
- Harmless to tyres and wheels

USAGE

In case of emergency.

DIRECTION/DOSAGE

Shake the aerosol and warm it up between your hands if necessary. If possible extract the cause of damage. Carefully screw the supply valve of the can to the valve of the tyre. Inject the entire content of the can while keeping it in an upright position. Drive to the nearest service station at a moderate speed. Carefully let out the compressed gas previously injected and reset the original pressure level of the tyre with compressed air.

RECOMMENDED DOSAGE

Bicycles	200 ml
Mopeds	300 ml
Passenger cars and motorcycles	400 ml
Large passengers cars and SUV's	500 ml

It is recommended after repair to have the tyre checked and/or replaced by a specialist.